

Overview of Instrument Talks

Optical imager — GigaCam

Electronics architecture

ASIC development

NIR imager — NIRcam/WNIRcam

Spectrographs

HgCdTe technology for SNAP

CCD technology

Chris Bebek

Henrik von der Lippe

Gerard Smadja


Greg Tarlé

Eric Prieto

James Graham

Steve Holland (Friday)

SNAP “Baseline”



Instrument Deployment



In the baseline design, the instruments each have their own light pick-off and focal plane.

This raises three concerns:

1. Establishing and keeping the instruments in focus simultaneously.
2. Establishing strong coupling between the precision star guiders and the focal planes.
3. A second complex light path has to be created if we want an IR imager larger than 1' x 1'.

A concept in early development is to coalesce the instruments around the main focal plane, **FIDO**, fully integrated focal plane option.

Issues associated with FIDO:

- Differing plate scales of CCDs and IR detectors due to different pixel sizes.
- Potentially different operating temperatures for CCDs and IR detectors.
- Implementation of shutter and filters.

Decision will be made in June-July 2001.

FIDO Example



Components:

- 236 CCDs
- 24 1k x 1k HgCdTe
- 2 spectrographs
- 8 star guider CCDs

IR:



0.028 sq. deg.

0.125 asec/pixel

Visible:

0.87 sq. deg.

0.07 asec/pixel





GigaCam

An Optical Imager for SNAP


Chris Bebek
Cornell University/LBNL

Overview



Talk overview

- Development and commercialization of a new CCD.
- Gearing up to demonstrate that the CCDs are scientific grade devices.
- Our plan to understand the CCDs performance in a space.
- Development of packaging technology to allow a large mosaic.
- Development of radiation shielding concept.



Science driven requirements



Populate $1^\circ \times 1^\circ$ focal plane with small dead space.

Broad spectral response with high quantum efficiency.

Low read noise to allow stacking multiple exposures.

Low dark current to support long exposures.

Stable performance in presence of radiation (>3 yrs).

Field-of-view	Approximately $1^\circ \times 1^\circ$
Plate Scale	0.07 to 0.10 arcsec/pixel (0.10 nominal)
Pixelization	Approx. 32k x 32k CCD mosaic
Wavelength coverage	350 nm – 1000 nm
Detector Type	High-Resistivity p-channel CCDs
Detector Architecture	2.5k x 2.5k, 12 or 10.5 μm pixel
Detector Array Temperature	135 - 150 K
Detector Quantum Efficiency:	65% @ 1000 nm, 92% @ 900 nm, >85% @ 400-800 nm
Photometric Accuracy	1% relative
Read Noise	4 e- @ 100 kHz
Exposure Time	100 sec to 1000 sec (single exposures)
Dark Current	0.04 e-/sec/pixel
Readout Time	20 sec

Main R&D issues

- Develop and commercialize a new type of CCD.
- Packaging the CCDs that allows efficient tiling of a focal plane.
- Protecting the CCDs from thermal and particle backgrounds.

Technical challenges

- Producing 300 μm thick, 150 mm wafers at a commercial foundry.
- Testing large numbers of devices.

Why Develop a New CCD?



We believe we can uniquely achieve the following attributes:

**Populate $1^\circ \times 1^\circ$ focal plane with small dead space,
88% packing efficiency.**


**Broad spectral response with high quantum efficiency,
High QE from 350 nm to 1000 nm.**

**Low read noise to allow stacking multiple exposures,
 $2e^-$ at 100 kHz read rate.**

**Low dark current to support long exposures,
 $0.001 e^-/s$.**

**Stable performance in presence of radiation (>3 years).
Radiation tolerant charge transfer, dark current, and read noise.**

New CCD Technology



Advantages:

- 1) Conventional MOS processes with no thinning => "inexpensive"
- 2) Full quantum efficiency to $> 1 \mu\text{m}$ => no fringing
- 3) Good blue response with suitably designed rear contact
- 4) Radiation tolerant

Disadvantages:

- 1) Enhanced sensitivity to radiation (x-rays, cosmic rays, radioactive decay)

- New kind of CCD developed at UCB/LBNL.
- High resistivity, *n*-type, *p*-channel, fully depleted silicon – same as used in HEP silicon vertex detectors.
- Rear illuminated.
- Antireflection coating.
- Thin polysilicon window for good blue response.
- Good QE at 1 μm and no fringing – 300 μm thickness and $I_{\text{abs}} \sim 100 \mu\text{m}$.
- No costly thinning of devices.
- High-purity silicon has better radiation tolerance for space applications.

Steve Holland will talk more on the technology Friday afternoon.

Charge transfer efficiency

Charge dependence

T dependence

Radiation damage

Read noise

Readout rate

Radiation damage

Defects

Erase

Cross talk

Clock shaping

Diffusion

Pixel size

Well depth

Intra-pixel response

Yield


Grinding/polishing

Quality

Precision assemblies

Shielding



LBNL 2k x 2k




First large format CCD made at LBNL

2k x 2k, 15 μm pixels.

1980 x 800, 15 μm pixels.



LBNL 2k x 2k results



Quantum efficiency

**Note uniquely high QE
from 0.7 μm to 1 μm .**

Measurements courtesy of Lick/UCSC.

LBNL 2k x 2k results





Image: 200 x 200 15 μ m LBNL CCD in Lick Nickel 1m.

Spectrum: 800 x 1980 15 μ m LBNL CCD in NOAO KPNO spectrograph.

USAF test pattern.



LBNL 2KX4K #1 R(17) -135c image



Size: 512 Rows, 272 Cols Origin (0,0)

Trap sites found
by pocket pumping.

LBNL 2KX4K #1 R(17) -135c pol



1478 x 4784
10.5 mm

2k x 4k
15 mm

1294 x 4186
12 mm

Measurements courtesy of Lick/UCSC.



In February, the Micro Systems Lab will start production of wafers concentrating on 2k x 4k 15 μm devices.

There will be no SNAP specific devices on the wafers.



Rather, we will use the yields of this run to understand MSL's role as a backup foundry for SNAP.

Four SNAP-sized CCDs can be fit on a dedicated 100 mm wafer.

Commercial 2k x 2k



The LBNL 2k x 2k layout and recipe where transferred to a commercial foundry.




Commercial PIN Diodes



**Array of 3 mm x 3 mm PIN diodes
on a 150 mm diameter wafer.
Due January 2001.**

**First use of 300 ~~mm~~ 150 mm wafer
by the vendor – usually 600 ~~mm~~.**

**This will be wafer probed to make
an x-y dark current to look for any
variations in processing.**



Commercial SNAP CCD



January submission.

Lot 1 - 150 mm, 600 μm thick.

Lot 2 - 150 mm, 300 μm thick.

Will contain SNAP CCDs

2.5k x 2.5k 12 μm w/ vertical notch.


2.5k x 2.5k 12 μm w/o vertical notch.

2.8k x 2.8k 10.5 μm .

Will see if vendor can meet 7 week delivery for lot 1 and 16 weeks for lot 2.

CCD size is chosen to fit within vendor's reticles, minimize charge transfer length, yet take advantage of large format to reduce parts count. The size also populates an LBNL 4" wafer efficiently.

A dedicated SNAP run can have 9 devices per wafer.



SNAP CCD Concept



2 x 2860 x 1430 10.5 μm

or


2 x 2520 x 1260 12.0 μm

4-corner and 2-corner readout.

Read noise as low as 2 e.

Sensitivity as high as 6 mV/e .


**Has top and bottom frame store
(not shown).**



CCD Details




The figure is an abstraction of the serial register neighborhood.



Define

- Parallel
- Serial
- Read noise





Remember the two transistors for later.



Test Facilities



- 3 dewars
- 2 Leach readout controllers
- 2 SUN workstations
- PC with CD-RW
- Vacuum furnace
- -40C refrigerator
- Class 10000 clean room
- Wire-bonder




IR Labs Dewar




CCDs are operated at a nominal 150 K to make dark current small.

We use LN_2 , a thermal switch, and a cold finger pressing against a face of the CCD (typically mounted on an AlN wafer).



Local electronics

CCD



Heater

Rapid Cycle Dewar



Chicken feeder dewar — ancient LBNL technology.

Quick release access plates, small volume and mass should give a cool-down/warm-up cycle under 2 hours.




Image Analysis Software



IDL program started last summer by a student.

Easily extended to automate newly developed analysis routines or data views.

Analysis tool. →

Dynamic window associated with analysis mode. →

The screenshot shows the 'CCD_ANALYZE' window with the following sections:

- READ FILE:** A 'read' button and a text field for 'read from:' containing '/home/design/karcher/ccd/1100x800_w2b_2/im_erase_steve102', with a 'browse' button.
- PRINT FILE:** 'open' and 'close' buttons, and a 'print to:' text field containing '/home/design/karcher/wfknew/steve102_darkcurrentfit.ps'.
- IMAGE REGION:** Includes a 'limit region' checkbox, 'COL: from 750 to 950', and 'ROW: from 0 to 600'.
- AXIS RANGES:** Includes 'Xrange' and 'Yrange' checkboxes, 'X from 750 to 950', and 'Y from 0 to 600'.
- Analysis Tools:** A row of buttons: 'FRAME', 'LINE PLOT', 'HISTOGRAM', 'GAUSS FIT', 'RMS', 'CTE', 'DARK CURRENT', and 'SURFACE PLOT'.
- DARK CURRENT:** Includes a 'run' button, 'COL: from 1 to 1290', 'ROW: from 0 to 700', 'range 1: from 200 to 1000', and 'range 2: from 1150 to 1290'.
- Options:** A list of options with checkboxes: 'display row(s)', 'display column(s)', 'write dc to file', 'don't fit', 'fit lines', and 'fit gaussians'. A text field below contains '/home/design/karcher'.
- QUIT:** A button at the bottom left.


JAVA Controller Software



Adding functionality to the Voodoo JAVA interface.

Interactive modification of clock and bias voltages without reboots (required DSP code mods).

Add ability to gracefully enter and exit erase mode (required DSP code mods).










Non-optical Measurements



Read noise

Dark current

Charge Transfer Efficiency




Read Noise Measurements




Noise after correlated double sampling.

Low capacitance readout geometry.
Read noise of 2e and sensitivity of 6 mV/e.






Sample time is the width of the reset or video integration.



Measurements courtesy of Lick/UCSC.

Dark Current Measurement



Measured dark current per 1000 sec obtained by fitting image area and overscan areas and subtracting gaussian peaks.

Dark charge collected = $1.03 / (0.41 * 1000) = 0.0025 \text{ e-/s}$ or $9.0 \text{ e-/pixel/hour}$.

CTE Measurement



For every pixel to pixel charge transfer there is the potential for some charge loss.

CTI is the charge transfer inefficiency.

People often quote the more awkward complement, the charge transfer efficiency.

A CTI or CTE is quoted for both the serial and parallel transfers.

We use the Mn **ka** x-ray line of ^{55}Fe as a known deposition of 1620 electrons.

We see how well 1620 electrons is reconstructed as a function of position in the CCD.


CTI of 5×10^{-6} are typical.

$$\text{CTI} = 1 - \text{CTE}$$

$$\text{CTI}^n = (Q_1 - Q_n)/n = b \cdot n/a$$



$$\text{CTI} = b/a \text{ for } b/a \ll 1$$

(n is the number of rows or columns)



note

Commercially-fabricated 1100x800 tested at LBNL



Optical Measurements




Present abilities

- Linearity
- Well depth
- Erasure

Need to develop

- CTE vs charge
- QE
- MTF
- Trap density
- Cross talk



View showing dewar with attached shutter and Optoliner projector fitted with Nikon macro lens and xyz stage.

Linearity and Well Depth




Well depth is a function of pixel size.

We are interested in small pixel sizes for SNAP to minimize area.

We have 10.5, 12, and 15 μm pixel sizes to test.

Scaling law is not obvious and needs to be measured.

Preliminary 12 μm well depth found to be 150 ke.



- Saturation curve obtained by plotting peak projected spot intensity versus exposure time.
- Full-well capacity in electrons obtained by scaling ADU's by CCD gain.



Persistent Images




Saturated images
can persist for hours.

We have an effective
erasing technique —
flood channels with
electrons.



Observe lowest dark
currents after an erase
cycle.



Saturating exposure



Persistent image



Erased image

Radiation Tolerance



**Radiation testing done at LBNL 88" Cyclotron with 12 MeV protons.
(Scaling other results at different energies is straight forward.)**

**We measure FET I-V and sub-threshold curves (300 K), dark current,
read noise, and serial and parallel CTE pre- and post-radiation (150 K).**

**The will be an ongoing activity for the next two years – large phase space
to map out.**

Tested devices (all 15 mm)


CCD	Type	Radiation Dose (protons/cm ²)		
		1st Pass Total	2nd Pass Total	3rd Pass Total
W4U	1100 x 800	5.0x10 ⁸	5.0x10 ⁹	
W2U	1100 x 800	1.0x10 ⁹	1.0x10 ¹⁰	
W2L	1100 x 800	5.0x10 ⁹	2.0x10 ¹⁰	

Devices were exposed at room temperature and unpowered.


Radiation Tolerance cont.



CTI vs Radiation Dose




An estimated NIEL dose for 3 years during solar max is 2×10^7 MeV/g.
This is equivalent to 10^9 12 MeV protons.



Radiation Tolerance cont.



Dark Current vs Radiation Dose



Radiation Tolerance cont.



- Near future plans:
 - After making some scheduled improvements in the test instrumentation (system noise reduction, better temperature regulation), we plan to incrementally increase the proton dose levels on the above CCD's to obtain additional damage data.
 - Irradiate Commercialized CCD's for comparison.
 - Developing new test protocols designed to produce additional damage information, *e.g.*, pocket pumping to monitor trap development.
- CCD improvements
 - We note that the serial register already has an additional notch implant in the channel for enhanced small charge CTE and radiation tolerance.
 - In the 12 μm device we are submitting, the parallel channels will also have a notch implant.

Diffusion



Diffusion



Issue

Diffusion scale for 300 μm thick CCD is 7 μm at 60V depletion.

This is comparable with the Airy disk width for $D=2\text{m}$, $FL=20\text{m}$: 5 μm at 10000A.

Can dilute the impact linearly by increasing the FL.

Can dilute the impact by $V^{-1/2}$ and/or thickness¹.



Diffusion cont.



Diffusion

Scaling law




$$D = (2 \cdot k \cdot T / q) \cdot \mu_p = 13 \text{ mV} \cdot \mu_p \text{ at } 150 \text{ K}$$

$$\sigma = \text{Sqrt}(2 \cdot D \cdot t)$$

$t = d / v_{\text{drift}}$ where d is the thickness

$$v_{\text{drift}} = \mu \cdot E$$

$$\sigma = \text{Sqrt}(0.026 \cdot d / E) = \text{Sqrt}(0.026 \cdot d^2 / V)$$





CCD Packaging



Packaging

- Support CCD
- Connection to cold plate
- Four-side abuttable for dense mosaic.
- Build-in mechanical precision – no shimming.
- Access to bonding pads
- Local electronics
- Cable connector
- Low background radiation materials



CCD Assembly




Class 10000 cleanroom

- Laminar flow bench
- Wire-bonder



Alignment and gluing assembly fixture

- Works for devices as large as 2k x 4k, 15 mm.
- Vacuum chuck can go into 150 C oven, if req'd.
- Vacuum chuck fits under wire-bonder head.




CCD
module

Mosaic Packaging




With precision CCD modules, precision baseplate, and adequate clearances designed in, the focal plane assembly is “plug and play.” Final assembly can be surveyed cold.



Develop a CCD focal plane shield concept to reduce:

- **Stray light.**
- **Particle backgrounds** — calculate doses on imager; do electronics exposure at the same time.
- **Black body** thermal loads.





Particle Shielding



Particle background has two components

- Solar protons — sub-100 MeV
- Galactic cosmic

Solar protons are most damaging to CCDs and some shielding makes a big impact.



Design a shield by minimizing the convolution of flux, material attenuation, and energy loss in silicon.


Thermal Shielding





Black body at 300 K is a thermal load, **not** an optical load, $\sim 450 \text{ W/m}^2$.

GigaCam is $\sim 0.1 \text{ m}^2$, **P** $\sim 50 \text{ W}$ if nothing done.


Use the particle shield as a thermal baffle to reduce solid angle.



GigaCam Assembly



GigaCam Mounted in SNAP



Summary



The high resistivity, *n*-type, *p*-channel, fully depleted silicon technology has produced functioning CCDs with good noise and QE performance.

Early evidence is that the technology is sufficiently radiation tolerant for the SNAP mission.

The commercial foundry has made successful parts.

We will exercise this foundry several times over the next 18 months.

SNAP-like parts will be available in April.

300 μ m thick, AR coated parts available in June.

We have built a team to test CCDs.

We will be expanding our test capabilities to do more types of optical measurements.

The next 18 months will see a lot of detailed measurements to fully understand the device characteristics.

From the above activities, we will have a good grasp on the time and effort and associated costs to produce CCDs for GigaCam.